

PROTON

Table of Contents

1	Vehicle models covered.....	1
2	Vehicle systems covered.....	1
3	Vehicle Special Function covered.....	6

1 Vehicle models covered

Model	Model	Year	Year
PROTON	ARENA	Updata to 2016	All
PROTON	CHANCELLOR	Updata to 2016	All
PROTON	EXPRA	Updata to 2016	All
PROTON	GEN-2CENTRAL ELECTRONIC	Updata to 2016	All
PROTON	INSPIRA	Updata to 2016	All
PROTON	JUARA	Updata to 2016	All
PROTON	PERDANA	Updata to 2016	All
PROTON	PERSONA	Updata to 2016	All
PROTON	PUTRA	Updata to 2016	All
PROTON	SAGA BLM	Updata to 2016	All
PROTON	SAGA FL	Updata to 2016	All
PROTON	SATRIA	Updata to 2016	All
PROTON	SATRIA NEO	Updata to 2016	All
PROTON	SAVVY	Updata to 2016	All
PROTON	WAJA	Updata to 2016	All
PROTON	WIRA	Updata to 2016	All
PROTON	EXORA BOLD	Updata to 2016	All
PROTON	Impian	Updata to 2016	All
PROTON	Jumbuck	Updata to 2016	All
PROTON	PREVE	Updata to 2016	All
PROTON	Perdana V6	Updata to 2016	All
PROTON	Persona Elegance(Dom)	Updata to 2016	All
PROTON	Persona Export	Updata to 2016	All
PROTON	Saga FLX	Updata to 2016	All
PROTON	Satria Gti	Updata to 2016	All
PROTON	Suprema S	Updata to 2016	All
PROTON	Waja Campro	Updata to 2016	All

2 Vehicle systems covered

Mode Name	System	DTC	Data List	Active Test	Special Func
ARENA	Engine Control System	X	X	X	X
ARENA	Automated manual transmission Braking System	X	X	X	X

Mode Name	System	DTC	Data List	Active Test	Special Func
ARENA	Immobilizer (IMMO)	X	X		X
Jumbuck	Engine Control System	X	X	X	X
Jumbuck	Automated manual transmission Braking System	X	X	X	X
Jumbuck	Immobilizer (IMMO)	X	X		X
CHANCELLOR	Engine Control System	X	X	X	X
CHANCELLOR	Automated manual transmission Braking System	X	X	X	X
CHANCELLOR	Antilock Brake System (ABS)	X	X	X	X
GEN-2CENTRAL ELECTRONIC	Engine Control System	X	X	X	X
GEN-2CENTRAL ELECTRONIC	Automated manual transmission Braking System	X	X	X	X
GEN-2CENTRAL ELECTRONIC	Antilock Brake System (ABS)	X	X	X	X
GEN-2CENTRAL ELECTRONIC	SRS-AIRBAG	X	X		X
GEN-2CENTRAL ELECTRONIC	Immobilizer (IMMO)	X	X		X
JUARA	Engine Control System	X	X	X	X
JUARA	Automated manual transmission Braking System	X	X	X	X
JUARA	Electric Power Steering (EPS)	X	X	X	
PERDANA	Engine Control System	X	X	X	X
PERDANA	Automated manual transmission Braking System	X	X	X	X
PERDANA	Antilock Brake System (ABS)	X	X	X	X
Perdana V6	Engine Control System	X	X	X	X
Perdana V6	Automated manual transmission Braking System	X	X	X	X
Perdana V6	Antilock Brake System (ABS)	X	X	X	X
PUTRA	Engine Control System	X	X	X	X
PUTRA	Antilock Brake System (ABS)	X	X	X	X
PUTRA	Automated manual transmission Braking System	X	X	X	X
PUTRA	SRS-AIRBAG	X	X		X
PUTRA	Immobilizer (IMMO)	X	X		X
SATRIA	Engine Control System	X	X	X	X
SATRIA	Automated manual transmission Braking System	X	X	X	X
SATRIA	Antilock Brake System (ABS)	X	X	X	X
SATRIA	Immobilizer (IMMO)	X	X		X
Satria Gti	Engine Control System	X	X	X	X
Satria Gti	Automated manual transmission Braking System	X	X	X	X
Satria Gti	Antilock Brake System (ABS)	X	X	X	X
Satria Gti	Immobilizer (IMMO)	X	X		X
WAJA	Engine Control System	X	X	X	X
WAJA	Automated manual transmission Braking System	X	X	X	X
WAJA	Antilock Brake System (ABS)	X	X	X	X
WAJA	Immobilizer (IMMO)	X	X		X
WAJA	SRS-AIRBAG	X	X		X

Mode Name	System	DTC	Data List	Active Test	Special Func
Waja Campro	Engine Control System	X	X	X	X
Waja Campro	Automated manual transmission Braking System	X	X	X	X
Waja Campro	Antilock Brake System (ABS)	X	X	X	X
Waja Campro	Immobilizer (IMMO)	X	X		X
Waja Campro	SRS-AIRBAG	X	X		X
Impian	Engine Control System	X	X	X	X
Impian	Automated manual transmission Braking System	X	X	X	X
Impian	Antilock Brake System (ABS)	X	X	X	X
Impian	Immobilizer (IMMO)	X	X		X
Impian	SRS-AIRBAG	X	X		X
WIRA	Engine Control System	X	X	X	X
WIRA	Automated manual transmission Braking System	X	X	X	X
WIRA	Antilock Brake System (ABS)	X	X	X	X
WIRA	Immobilizer (IMMO)	X	X		X
SAVVY	Engine Control System	X	X	X	X
SAVVY	Automated manual transmission Braking System	X	X	X	X
SAVVY	Antilock Brake System (ABS)	X	X	X	X
SAVVY	SRS-AIRBAG	X	X		X
SATRIA NEO	Engine Control System	X	X	X	X
SATRIA NEO	Automated manual transmission Braking System	X	X	X	X
SATRIA NEO	Antilock Brake System (ABS)	X	X	X	X
SATRIA NEO	Immobilizer (IMMO)	X	X		X
SATRIA NEO	SRS-AIRBAG	X	X		X
PERSONA	Engine Control System	X	X	X	X
PERSONA	Automated manual transmission Braking System	X	X	X	X
PERSONA	Antilock Brake System (ABS)	X	X	X	X
PERSONA	Immobilizer (IMMO)	X	X		X
PERSONA	SRS-AIRBAG	X	X		X
Persona Export	Engine Control System	X	X	X	X
Persona Export	Automated manual transmission Braking System	X	X	X	X
Persona Elegance(Dom)	Engine Control System	X	X	X	X
Persona Elegance(Dom)	Automated manual transmission Braking System	X	X	X	X
Persona Elegance(Dom)	Antilock Brake System (ABS)	X	X	X	X
Persona Elegance(Dom)	Immobilizer (IMMO)	X	X		X
Persona Elegance(Dom)	SRS-AIRBAG	X	X		X
Saga Blm	Engine Control System	X	X	X	X
Saga Blm	Automated manual transmission Braking System	X	X	X	X
Saga Blm	Antilock Brake System (ABS)	X	X	X	X
Saga Blm	Immobilizer (IMMO)	X	X		X
Saga Blm	SRS-AIRBAG	X	X		X
Saga FL	Engine Control System	X	X	X	X
Saga FL	Automated manual transmission Braking System	X	X	X	X

Mode Name	System	DTC	Data List	Active Test	Special Func
Saga FL	Antilock Brake System (ABS)	X	X	X	X
Saga FL	Immobilizer (IMMO)	X	X		X
Saga FL	SRS-AIRBAG	X	X		X
Saga FLX	Engine Control System	X	X	X	X
Saga FLX	Automated manual transmission Braking System	X	X	X	X
Saga FLX	Antilock Brake System (ABS)	X	X	X	X
Saga FLX	SRS-AIRBAG	X	X		X
EXORA	Antilock Brake System (ABS)	X	X	X	X
EXORA	Immobilizer (IMMO)	X	X		X
EXORA	SRS-AIRBAG	X	X		X
EXORA	Engine Control System	X	X	X	X
EXORA	Automated manual transmission Braking System	X	X	X	X
EXORA	Antilock Brake System (ABS)	X	X	X	X
EXORA	SRS-AIRBAG	X	X		X
EXORA	Body Control Module (BCM)	X			
EXORA	Central Electronic	X	X	X	
EXORA BOLD	Antilock Brake System (ABS)	X	X	X	X
EXORA BOLD	Immobilizer (IMMO)	X	X		X
EXORA BOLD	SRS-AIRBAG	X	X		X
EXORA BOLD	Engine Control System	X	X	X	X
EXORA BOLD	Automated manual transmission Braking System	X	X	X	X
EXORA BOLD	Antilock Brake System (ABS)	X	X	X	X
EXORA BOLD	SRS-AIRBAG	X	X		X
EXORA BOLD	Body Control Module (BCM)	X			
EXORA BOLD	Central Electronic	X	X	X	
EXORA BOLD	Instrumentation	X	X		
EXORA BOLD	Gear Control	X	X		
INSPIRA	SRS-AIRBAG	X	X		X
INSPIRA	Engine Control System	X	X	X	X
INSPIRA	Instrumentation	X	X		
INSPIRA	Antilock Brake System (ABS)	X	X	X	X
INSPIRA	Electronic time alarm control system	X	X		
INSPIRA	Auto Cruise		X		
INSPIRA	Heating Ventilation and air Conditioning	X	X	X	
INSPIRA	Immobilizer (IMMO)	X	X		X
INSPIRA	Lin	X	X	X	
PREVE	SRS-AIRBAG	X	X		X
PREVE	Engine Control System	X	X	X	X
PREVE	Automated manual transmission Braking System	X	X	X	X
PREVE	Central Electronic	X	X	X	
PREVE	Gear Control	X	X		
PREVE	Body Control Module (BCM)	X			
PREVE	Meter	X	X	X	X
PREVE	Instrumentation	X	X		
PREVE	Antilock Brake System (ABS)	X	X	X	X
Suprema S	SRS-AIRBAG	X	X		X

Mode Name	System	DTC	Data List	Active Test	Special Func
Suprima S	Engine Control System	X	X	X	X
Suprima S	Automated manual transmission Braking System	X	X	X	X
Suprima S	Central Electronic	X	X	X	
Suprima S	Gear Control	X	X		
Suprima S	Body Control Module (BCM)	X			
Suprima S	Meter	X	X	X	X
Suprima S	Instrumentation	X	X		
Suprima S	Antilock Brake System (ABS)	X	X	X	X

3 Vehicle Special Function covered

Mode Name	System	Special Function
Suprima S	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Suprima S	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
Suprima S	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Suprima S	ABS	EBC430 REPAIR CYCLE
Suprima S	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Suprima S	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Suprima S	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Suprima S	ENGINE	ALFTER IDLE SPEED
Suprima S	AT	READ OIL COUNTER READ OIL CHANGE DATE READ AFTER SALES DATE WRITE DATE AFTER SALES OPERATION WRITE OIL HCANGE DATE REINT OIL COUNTER REINT AUTO ADAPTIVE NOTE OIL COUNTER REINT CONVERT LOCKUP ADAPTIVE
Suprima S	ABS	EBC430 REPAIR CYCLE
Suprima S	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Suprima S	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
Suprima S	AT	CHANGE SETTINGS ERASE MENU SELFTTEST
Suprima S	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
Suprima S	ABS	EBC430 REPAIR CYCLE
Suprima S	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset

Mode Name	System	Special Function
		5 Test/limit value readout
Suprima S	AT	1 Provisional DTCs
Suprima S	METER	1 Diagnose mode start 2 Reminder reset 3 Next schedule reminder cancel 4 Extra reminder setting 5 Extra reminder cancel 6 Periodic reminder schedule set 7 Integrated value adjustment 8 Optional INT schedule setting
PREVE	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PREVE	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
PREVE	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PREVE	ABS	EBC430 REPAIR CYCLE
PREVE	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
PREVE	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PREVE	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PREVE	ENGINE	ALFTER IDLE SPEED
PREVE	AT	READ OIL COUNTER READ OIL CHANGE DATE READ AFTER SALES DATE WRITE DATE AFTER SALES OPERATION WRITE OIL HCANGE DATE REINT OIL COUNTER REINT AUTO ADAPTIVE NOTE OIL COUNTER REINT CONVERT LOCKUP ADAPTIVE
PREVE	ABS	EBC430 REPAIR CYCLE
PREVE	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
PREVE	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
PREVE	AT	CHANGE SETTINGS ERASE MENU SELFTTEST
PREVE	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
PREVE	ABS	EBC430 REPAIR CYCLE
PREVE	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
PREVE	AT	1 Provisional DTCs
PREVE	METER	1 Diagnose mode start 2 Reminder reset 3 Next schedule reminder cancel 4 Extra reminder setting

Mode Name	System	Special Function
		PREVE 5 Extra reminder cancel 6 Periodic reminder schedule set 7 Integrated value adjustment 8 Optional INT schedule setting
ARENA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
ARENA	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
ARENA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
ARENA	ABS	EBC430 REPAIR CYCLE
ARENA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
ARENA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
ARENA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
ARENA	ENGINE	ALFTER IDLE SPEED
ARENA	ABS	EBC430 REPAIR CYCLE
ARENA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
ARENA	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
ARENA	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
ARENA	ABS	EBC430 REPAIR CYCLE
ARENA	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
Jumbuck	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Jumbuck	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
Jumbuck	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Jumbuck	ABS	EBC430 REPAIR CYCLE
Jumbuck	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Jumbuck	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Jumbuck	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Jumbuck	ENGINE	ALFTER IDLE SPEED
Jumbuck	ABS	EBC430 REPAIR CYCLE
Jumbuck	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Jumbuck	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED

Mode Name	System	Special Function
		INJ CONTROL UNLOCKED
Jumbuck	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
Jumbuck	ABS	EBC430 REPAIR CYCLE
Jumbuck	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
CHANCELLOR	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
CHANCELLOR	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
CHANCELLOR	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
CHANCELLOR	ABS	EBC430 REPAIR CYCLE
CHANCELLOR	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
CHANCELLOR	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
CHANCELLOR	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
CHANCELLOR	ENGINE	ALFTER IDLE SPEED
CHANCELLOR	ABS	EBC430 REPAIR CYCLE
CHANCELLOR	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
CHANCELLOR	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
CHANCELLOR	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
CHANCELLOR	ABS	EBC430 REPAIR CYCLE
CHANCELLOR	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
GEN-2	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
GEN-2	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
GEN-2	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
GEN-2	ABS	EBC430 REPAIR CYCLE
GEN-2	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
GEN-2	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
GEN-2	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
GEN-2	ENGINE	ALFTER IDLE SPEED
GEN-2	ABS	EBC430 REPAIR CYCLE
GEN-2	AIRBAG	LOCKING OF IGNITION

Mode Name	System	Special Function
		UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
GEN-2	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
GEN-2	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
GEN-2	ABS	EBC430 REPAIR CYCLE
GEN-2	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
JUARA	ENGINE	VHHCLE CONFIGURATION ADJUST IDLE SPEED
JUARA	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
JUARA	ENGINE	VHHCLE CONFIGURATION ADJUST IDLE SPEED
JUARA	ABS	EBC430 REPAIR CYCLE
JUARA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
JUARA	ENGINE	VHHCLE CONFIGURATION ADJUST IDLE SPEED
JUARA	ENGINE	VHHCLE CONFIGURATION ADJUST IDLE SPEED
JUARA	ENGINE	ALFTER IDLE SPEED
JUARA	ABS	EBC430 REPAIR CYCLE
JUARA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
JUARA	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
JUARA	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
JUARA	ABS	EBC430 REPAIR CYCLE
JUARA	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
PERDANA	ENGINE	VHHCLE CONFIGURATION ADJUST IDLE SPEED
PERDANA	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
PERDANA	ENGINE	VHHCLE CONFIGURATION ADJUST IDLE SPEED
PERDANA	ABS	EBC430 REPAIR CYCLE
PERDANA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
PERDANA	ENGINE	VHHCLE CONFIGURATION ADJUST IDLE SPEED

Mode Name	System	Special Function
PERDANA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PERDANA	ENGINE	ALFTER IDLE SPEED
PERDANA	ABS	EBC430 REPAIR CYCLE
PERDANA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
PERDANA	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
PERDANA	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
PERDANA	ABS	EBC430 REPAIR CYCLE
PERDANA	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
Perdana V6	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Perdana V6	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
Perdana V6	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Perdana V6	ABS	EBC430 REPAIR CYCLE
Perdana V6	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Perdana V6	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Perdana V6	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Perdana V6	ENGINE	ALFTER IDLE SPEED
Perdana V6	ABS	EBC430 REPAIR CYCLE
Perdana V6	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Perdana V6	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
Perdana V6	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
Perdana V6	ABS	EBC430 REPAIR CYCLE
Perdana V6	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
PUTRA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PUTRA	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
PUTRA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PUTRA	ABS	EBC430 REPAIR CYCLE
PUTRA	AIRBAG	LOCKING OF IGNITION

Mode Name	System	Special Function
		UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
PUTRA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PUTRA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
PUTRA	ENGINE	ALFTER IDLE SPEED
PUTRA	ABS	EBC430 REPAIR CYCLE
PUTRA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
PUTRA	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
PUTRA	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
PUTRA	ABS	EBC430 REPAIR CYCLE
PUTRA	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
SATRIA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
SATRIA	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
SATRIA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
SATRIA	ABS	EBC430 REPAIR CYCLE
SATRIA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
SATRIA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
SATRIA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
SATRIA	ENGINE	ALFTER IDLE SPEED
SATRIA	ABS	EBC430 REPAIR CYCLE
SATRIA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
SATRIA	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
SATRIA	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
SATRIA	ABS	EBC430 REPAIR CYCLE
SATRIA	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
Satria Gti	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Satria Gti	IMMO	SIEMENS IMMOBILIZER KEY CODING

Mode Name	System	Special Function
		SIEMENS IMMOBILIZER KEY CLEAR
Satria Gti	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Satria Gti	ABS	EBC430 REPAIR CYCLE
Satria Gti	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Satria Gti	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Satria Gti	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Satria Gti	ENGINE	ALFTER IDLE SPEED
Satria Gti	ABS	EBC430 REPAIR CYCLE
Satria Gti	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Satria Gti	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
Satria Gti	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
Satria Gti	ABS	EBC430 REPAIR CYCLE
Satria Gti	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
WAJA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
WAJA	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
WAJA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
WAJA	ABS	EBC430 REPAIR CYCLE
WAJA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
WAJA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
WAJA	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
WAJA	ENGINE	ALFTER IDLE SPEED
WAJA	ABS	EBC430 REPAIR CYCLE
WAJA	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
WAJA	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
WAJA	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
WAJA	ABS	EBC430 REPAIR CYCLE
WAJA	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value

Mode Name	System	Special Function
		4 Learned value reset 5 Test/limit value readout
Impian	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Impian	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
Impian	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Impian	ABS	EBC430 REPAIR CYCLE
Impian	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Impian	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Impian	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Impian	ENGINE	ALFTER IDLE SPEED
Impian	ABS	EBC430 REPAIR CYCLE
Impian	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Impian	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
Impian	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
Impian	ABS	EBC430 REPAIR CYCLE
Impian	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
SAVVY	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
SAVVY	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
SAVVY	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
SAVVY	ABS	EBC430 REPAIR CYCLE
SAVVY	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
SAVVY	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
SAVVY	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
SAVVY	ENGINE	ALFTER IDLE SPEED
SAVVY	ABS	EBC430 REPAIR CYCLE
SAVVY	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
SAVVY	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
SAVVY	ABS	VEHICLE CONFIGURATION

Mode Name	System	Special Function
		ADJUST IDLE SPEED
SAVVY	ABS	EBC430 REPAIR CYCLE
SAVVY	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
Persona	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Persona	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
Persona	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Persona	ABS	EBC430 REPAIR CYCLE
Persona	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Persona	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Persona	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Persona	ENGINE	ALFTER IDLE SPEED
Persona	ABS	EBC430 REPAIR CYCLE
Persona	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Persona	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
Persona	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
Persona	ABS	EBC430 REPAIR CYCLE
Persona	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout
Saga	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Saga	IMMO	SIEMENS IMMOBILIZER KEY CODING SIEMENS IMMOBILIZER KEY CLEAR
Saga	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Saga	ABS	EBC430 REPAIR CYCLE
Saga	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES WRITE DATE OF AFTER SALES
Saga	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Saga	ENGINE	VHHICLE CONFIGURATION ADJUST IDLE SPEED
Saga	ENGINE	ALFTER IDLE SPEED
Saga	ABS	EBC430 REPAIR CYCLE
Saga	AIRBAG	LOCKING OF IGNITION UNLOCKING OF IGNITION READ DATE OF AFTER SALES

Mode Name	System	Special Function
		WRITE DATE OF AFTER SALES
Saga	ENGINE	REINITIALISE PROGRAMMING INJ CONTROL LOCKED INJ CONTROL UNLOCKED
Saga	ABS	VEHICLE CONFIGURATION ADJUST IDLE SPEED
Saga	ABS	EBC430 REPAIR CYCLE
Saga	ENGINE	1 Provisional DTCs 2 All Learned value 3 Read&Write learned value 4 Learned value reset 5 Test/limit value readout